

## No More Gaps® Timber Flooring

### Description

No More Gaps® Timber Flooring gap filler is specially designed for filling and sealing gaps around and between tongue & groove timber flooring and also between other timber panels and fittings where extra flex is required. It is formulated to provide superior, long lasting resistance to the movement of hardwood timber floorboards and other timber panels and fittings, created by temperature and humidity changes.

### Product Information

Packaging	Size	Colour
Cartridge	380 grams	Hardwood
Cartridge	380 grams	Baltic
Cartridge	380 grams	Jarrah
Cartridge	380 grams	Walnut

### Uses

Use No More Gaps® Timber Flooring for filling and sealing gaps in hardwood timber floors and between all types of timber panels and fittings eg. Bedroom and kitchen fittings, bench tops, skirting boards, and architraves

### Technical Features

- Superior, long lasting resistance to movement of hardwood timber floors
- Four timber colours to match a wide range of timber types
- Sandable – contains real wood fibre
- Can be stained, varnished or painted
- Water clean up
- Airtight seal

### Technical Details

Property	Typical Result
Appearance	Smooth Paste
Technology	Water Evaporation
Joint Movement capability	+/-25% (ISO 9046)
Elongation	+500%
Shore A Hardness	Greater than 50
Peel Strength	Up to 110N (Anodised aluminium)
Ultimate Tensile Strength	0.4MPa

Indicative data only, not intended for preparation of specifications

### How To Use

#### Application

1. Surface to be filled must be clean, dry and free from dust.
2. Cut seal & nozzle to suit width of gap. Fit to cartridge. Insert into caulking gun.
3. Apply with caulking gun, forcing product into gap.
4. Press in and smooth off with a spatula. Take care not to drag out applied filler from the gap. Use spatula to scrape off as much residue as possible from the timber surface to minimise sanding necessary
5. Clean up with a damp cloth immediately.
6. Allow to dry for at least 24 hours before sanding off any residue from timber surface. Allow longer time in colder weather or if residue left on timber is excessive.
7. Stain and varnish/paint as desired. Ensure stain/varnish is no allowed to pool in the joint – lightly wipe off while wet if necessary.

#### Clean Up

Uncured product may be removed with water. Cured product can be removed by sanding and scraping

#### Handy Hints

- Not for gaps >3mm wide in trafficable joints.
- Coverage: 18mm / 3mm bead.
- Ensure sufficient product is applied into gap, if filling tongue and groove overlaps.
- Re-apply filler if timber movement is excessive and movement capability s exceeded, or if a flush fill is desired.

#### Limitations

- Not for exterior use.

#### Warnings, First Aid and Shipping Information

This information can be located on the SDS found on the Selleys website – [www.selleys.com.au](http://www.selleys.com.au) or [www.selleys.co.nz](http://www.selleys.co.nz)